Warranty

GOLDENLOX Guide

1, 5 year warranty

Replacement warranty will be provided during he warranty period if the lamp suffers quality problems.


- 2, During the warrant period, the customer shall return the damaged goods or failed parts for inspection and repair by Goldenlx. Goldenlux will then send the fixed or new parts back.
- 3, Replacement warranty will be provided once valid documents are presented.
- 4, The following circumstances will not receive replacement warranty;

a,Damage caused, including, but not limited to, damage from abnormal working

conditions, improper usage, storage that does not conform to the instruction manual;

b,Dismantling, modification or improper installation or repairing of the products without Goldenlux's authorisation; c,No valid documents;

d, Damages caused by environmental circumstances including, but not limited to, fire, flood, lighting strike, earthquake.



Web: www.goldenlux.cn Shenzhen Goldenlux Co., Ltd Niujiao Rd 1#, Yanchuan 2nd Industrial Area, Song'gang Town, Bao'an District, SZ, China

Mail:sales@goldenlux.cn

LED Canopy Light IP65 IK08 5 years warranty



Tel:+86 755 2300 4469


Warning

- 1, Carefully read the installation instructions and ensure the mains supply is isolated before installation
- 2, All electrical work must be undertaken by a qualified contractor to ensure latest wiring regulations.
- 3, Disconnect power before installing or doing any maintenance.
- 4, This light should not be used in areas with limited ventilation or high ambient temperatures.

Specification:


Model No.:	GL-CL80W	GL-CL100W	GL-CL120W	GL-CL150W	GL-CL180W	GL-CL200W
Wattage:	80W	100W	120W	150W	180W	200W
Lumens:	12000lm	15000lm	18000lm	22500lm	27000lm	30000lm
Beam Angle:	30°/40°/60° /90° /120° /40x110° pc lens+glass cover					
IP Rating:	IP65	IP65	IP65	IP65	IP65	IP65
N. W:	5.1KG	5.1KG	5.3KG	5.3KG	5.5KG	5.5KG
G. W:	6.0KG	6.0KG	6.2KG	6.2KG	6.4KG	6.4KG
Product Size:	400*400*80MM					
Packing Size:	450*450*140mm					

Fixture model and specification



🛠 Installation

Cut off the power before the lamp connected, connect the line as follow.




X Installation diagram

- 1. The wall holes keep same as the left picture.
- 2. Using the screws and adjust the angleto fix

the lamp on the wall .

3. According to the wiring instruction to use.



1. The wall holes keep same as the left picture. 2. Using the screws to lock the rear cover.

3.Put the lamp into the rear cover, locking with screw.

4. According to the wiring instruction to use.



1. The wall holes dimension keep same as left picture.


2.Put the lamp in it and then locked.3.According to the wiring instruction to use.



1. The wall holes dimension keep same as left picture.

2.Put the lamp in it.

3. According to the wiring instruction to use.



1. The wall holes dimension keep same as left picture.

2.Put the lamp in it ,lock the pole and power box.3.According to the wiring instruction to use.

