

LED HIGH BAY LIGHT

Instruction Manual

/ WARRANTΥ

- 2-year warranty replacement warranty will be provided during the warranty period if the lamp suffers quality problems.
- During the warranty period, the customer shall return the damaged goods or failed parts for inspection and repair by Goldenlux. Goldenlux will then send the fixed or new parts back.
- A replacement warranty will be provided once valid documents are presented.

\Lambda WARNING

To avoid the risk of fire, explosion, or electric shock:

This product should be installed, inspected, and maintained by a qualified electrician only, in accordance with all applicable electrical codes.

 \ast Verify power wire is by following per under applicable electrical codes.

& The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

& The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.

To avoid electric shock:

- Be certain electrical power is OFF before and during installation and maintenance.
- Luminaires must be supplied by a wiring system suitable per local code with an equipment grounding conductor.

To avoid burning hands:

 Before to performing maintenance, ensure Luminaire is allowed to cool after poweing off for a period of 30 minutes.

The following circumstances will not receive replacement warranty:

- ① Damage caused, including, but not limited to, damage from abnormal working conditions, improper usage, storage that does not conform to the instruction manual;
- Dismantling, modification or improper installation or repairing of the products without Goldenlux's authorization;
- (3) Damages caused by environmental circumstances including, but not limited to, fire, flood, lighting strike, earthquake.

To avoid product degradation:


- Do not operate in ambient temperatures above those indicated on the luminaire date sheet.
- Use proper supply wiring as specified on the luminaire date sheet.
- Avoid use in environments containing sulfur, chlorine or other halides, methyl acetate or ethyl acetate, cyanoacrylates, glycol ethers, formaldehyde, or butadiene.
- Mount luminaire no less than 36 inches from the ceiling.
- Make sure the supply voltage is within the voltage range stated on the date sheet.
- Use only replacement parts from Goldenlux.
- Aircraft cable mounting is recommended for dry locations only.
- Use only Goldenlux or equivalent parts for mounting luminaire.

MOUNTING

PENDANT EYEBOLT MOUNTING


STEP 1

Thread the enclosed eyebolt hook into the top of the luminaire housing, and tighten securely. Tighten the set screw to prevent the eyebolt from loosening.



STEP 2

Use a chain, cable, mounting hook, or other mounting hardware to suspend the luminaire. Make sure the mounting hardware is securely attached to a stationary structure and strong enough to safely be attached to a stationary structure and strong enough to safely suspend the luminaire.




Refer to the Wiring Diagram to make electrical connections.



CEILING MOUNTING:


STEP 1

Install the fixings of the ceiling mounting bracket to the back of the lamp, then connect the ceiling mounting bracket with the mounting bracket fixing parts.




STEP 2

Using the yoke mount bracket as a template, mark and drill holes in the ceiling or other solid structure to which the luminaire will be attached.




STEP 3


 $\ensuremath{\mathsf{Fix}}$ the lamp mounting bracket to the mounting surface with bolts and nuts.



STEP 4

If the luminaire will be installed at an angle, tighten the mounting bracket adjustment bolts only partially tight. Otherwise, securely tighten these bolts.





REFER TO THE WIRING DIAGRAM TO MAKE ELECTRICAL CONNECTIONS

